

**R-1029**

**996 CABRIOLET - HARNESS MOUNT  
INSTALLATION INSTRUCTIONS**

Note: Brey-Krause part# R-1029 harness mount bar has been designed to properly locate and mount the shoulder harness portion of a 5 point or 6 point restraint in a 996 cabriolet.

Steps 1 - 9 are for installing mounting brackets that will remain in the car. This will make the installation and removal of the bar faster and easier and will eliminate the constant removal and installation of fasteners in the body shell. - Loctite 242 or equivalent is recommended on all fasteners.

**Step 1**

Move seats to foremost position exposing rear seat track mounting bolts. Remove outside rear seat track mounting bolt along with the seat stop bracket. (Once the seat track mounting bolt is removed the seat stop bracket can be removed by gently prying upward to pop out the plastic retaining pin). Also: a 10 mm. Six point socket will work to remove the seat track mounting bolt. Repeat for the other side.



Figure 1A



Figure 1B

**Step 2**

Remove outside lap belt, mounting bolt and spacer located along the doorsill.



Figure 2

**Step 3**

Position large stepped spacer (supplied) at outside belt mounting point. This replaces the factory spacer. Next place lap belt end bracket over stepped spacer. Make sure the belt is oriented properly. Position the floor mount bracket as shown. Install supplied 2" long bolt and washer. **Note:** do not tighten and this time. (SEE ATTACHED DRAWING 1029-A)



Figure 3A



Figure 3B

**Step 4**

Reinstall original seat track mounting bolt. (Do not reinstall seat stop bracket.)

**Step 5**

Tighten bolts from steps 3 & 4. Repeat on other side.



Figure 5

**Step 6**

with velcro and are removed by lifting upward.



Figure 6

**Step 7**

Pry plastic caps off of the outside seat belt mounting points. Remove outside rear seat belt mounting bolts - (leave factory spacer in place.) Position the rear mounting bracket as shown. Install 1 3/4" long bolt with small stepped spacer thru the factory belt, mounting bracket and factory spacer. Repeat for other side. SEE ATTACHED DRAWING 1029-B)



Figure 7

**Step 8**

Reinstall the lower seat cushions.

### Step 9

Position main bar as shown. Note: you may have to lightly pry the rear mounting brackets to position the main bar between them. Install 7/8" long bolts and washers. (One for each side.) Do not tighten at this time.



Figure 9A



Figure 9B

### Step 10

Position support tube as shown and install 7/8" bolts and washers at each end as shown below. (Passenger side shown)



Figure 10A



Figure 10B

### Step 11

Tighten all fasteners. Completed installation should look like this.



Figure 11

**Note:** Periodically recheck fasteners for tightness. Shoulder straps should be wrap mounted around main tube and thru guides.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.